

## PORT-A-GUARD WALL MOUNT

BPG5 – Wallmount 3.2 metre

BPG7 – Wallmount 5.0 metre

### Fitting instructions:

1. Place bottom wallmount bracket against selected wall. Straight and flush with floor level. Attach with suitable fixings. (PHOTO 1).
2. Slide Port-a-guard over bottom wall mount. (PHOTO 2).
3. Place top wallmount bracket against the wall, and slide into the top of the Port-a-guard. (PHOTO 3).
4. Make sure wallmount is flush with Port-a-guard. Screw wallmount bracket firmly into place. The Port-a-guard is now permanently fixed in place. (PHOTO 4).

*Note: Do not install top bracket if the Port-a-guard is to be removed or made repositionable.*

**\* Additional brackets are available, if required.**

5. Finished, Port-a-guard Wallmount is ready for use. (PHOTO 5).



1.



2.



3.



4.



5.